TECWARE

PHANTOM ELITE

BACKLIT MECHANICAL KEYBOARD

Quick Start Guide

Key Features



① My Computer
② Internet Explorer
③ Calculator
④ Media Player
⑤ Reverse
⑥ Forward
⑦ Play / Pause
⑧ Stop
⑨ Volume Mute
⑩ Volume Decrease
⑪ Volume Increase
⑫ Num Lock Indicator
⑬ Caps Lock Indicator
⑭ Windows Lock Indicator
⑮ LED Lighting Direction
⑯ RGB Color
⑰ Lighting Mode 1
⑱ Lighting Mode 2
⑲ Lighting Mode 3
⑳ Lighting Mode 4
㉑ Lighting Mode 5
㉒ Lighting Mode 6
㉓ Windows Lock
㉔ Brightness Increase
㉕ Brightness Decrease
㉖ LED Lighting Speed Decrease
㉗ LED Lighting Speed Increase

Multimedia Function





Various LED modes can be triggered by Fn + Mode Keys



① Breathing - Cycle Color
② Breathing - Fixed Color
③ Fixed Color



① Reactive - Ripple
② Reactive - Single
③ Reactive - Horizontal



① Sine Wave
② Vortex
③ Rain Drops



① Horizontal Wave
② Pulse Wave
③ Hurricane



① Vertical Wave
② Waterfall
③ Swirl



① Diagonal Wave
② Fixed Color
③ Ripple

Spectrum Selection Mode

104 different LED colors can be triggered by Fn + RGB key. Simply press on the key with your preferred color. Selecting RGB key will give you rainbow mode.

More modes of functions can be accessed via our software. You can download it at ***www.tecware.co***
Software only works with Windows.



STEP 3 : Check switch pins

Please inspect each switch to make sure the switch pins are straight before inserting them to the keyboard. Make necessary adjustments if needed as inserting them with bent switch pins may further damage the switch.



STEP 4 : Inserting a new switch.

Align the switch pins to the holes of the keyboard. The switch will snap on to place and test immediately for response.

Package Contents

- TECWARE PHANTOM ELITE 104 Keys
- Spare Mechanical Switch x 4
- Keycap Puller x 1
- Switch Puller x 1

System Requirements

- PC with USB port
- Windows 7/8/10, Mac

Installation

- Plug your TECWARE PHANTOM ELITE 104 into the USB port of your PC.
  No driver installation is required for this product, the operating system should auto detect the keyboard when you plug it into your computer.

Warranty

- 1 Year. Please contact your local distributor for support.

Spare Mechanical Switch Kit

There might be occasions where a mechanical switch might fail. Please refer to our website at www.tecware.co for instructions on how to easily replace the faulty switch on your keyboard.



STEP 1 : Keycap Removal

Use the supplied keycap puller and press down on to the keycap to secure the puller on it. Pull the keycap puller directly upwards to remove the keycap. If the switch is removed as well, simply pull the keycap off the switch and just reattach the switch on to the keyboard.



STEP 2 : Switch Removal

Rotate the switch puller too to a vertical position to coincide with the switch locks located at the top and bottom of each switch. Push the switch locks in and pull the switch puller directly upwards. We suggest to take extra care when removing switches so as not to bend the switch pins. Please also take extra caution so as not to scratch the keyboard's backplate.

www.tecware.co